

Tryten P1 Tablet Cart



DESIGNED FOR:

TELEHEALTH COMMUNICATION

REMOTE INTERPRETING

VIRTUAL VISITING

VIRTUAL ROUNDING

EHR WORKFLOW SUPPORT



Size Adjustable Secure Tablet Bracket →

Articulating Arm →

Concealed Cable Management →

← Custom Branding Available

← Dozens of Peripheral Attachment Options

← Height Adjustable Utility Box

← Tip Resistant Weighted Base

Whisper Quiet Locking Wheels →

Tryten P1 Tablet Cart



Articulating Arm

Height adjustable 14" articulating arm with cart height reaching from 44.4" to 63".

Ergonomic Handle & Cord Wrap

Ergonomic handle with slender design uniquely placed for easy push-and-position.

Universal Tablet Security Bracket

Secures your tablet or iPad with lockable bracket. Locking bracket comes with 2 user keys, with or without-case sliders and supports a weight of up to 3.5lbs.

Tablet Tilt

Bracket comes with tablet tilt of 60 degrees, horizontal pan of 180 degrees and rotation around the axis of 360 degrees. Position your tablet at various angles for ease of use.

Customization

Customize your cart with Branding Options and 40+ Accessories.

Best-in-Class, Durable Materials

Anodized Aluminum, Powder-Coated Aluminum, Cyclopy Plastic, fully wipeable and approved in operating rooms.

Concealed Cable Management

Cable management channel allows for discreet and uninterrupted charging. Large utility box can house power cable receptacles or other power components.

Base & Casters

4-Wheel base balances the need for stability with a small footprint. Complete with premium, quiet, non-mark and locking casters, this cart is ready to roll or stay in a locked position as you need.

Quality & Services

5 Year Limited-Warranty, ISO 9001:2015 Certified, Tip Resistant as per IEC 60601, and Remote Expert Support.

DIMENSIONS AND SPECS

- Column Articulating Arm: 44.4" to 63" H
- Articulating Arm Rotation: 90 degrees
- Articulating Arm Reach: 19"
- Large Utility Box, Inside fit, 8.6" x 3.9" x 2.0"
- Large Utility Box, Outside, 9.2" x 5.5" x 2.8"
- Base footprint: 18.7" to 20.6"
- Tablet Size: 6.6" - 9.3"H to 9.5" - 12.95"
- Tablet Thickness: 0.36" to 0.74"
- Tablet weight limit: 3.5 lbs

WHAT'S INCLUDED

- P-Series Poll with Articulating Arm
- Base with Locking Casters
- Large Utility Box
- Handle and Cord Wrap
- Hardware Pack
- Assembly Instructions